

ACP Remote Programming Interface General User Guide



Use the ACP Remote Programming Interface to create and organize menu item information from your computer.

For MXP/AXP - touchscreen models, please see separate user guide, available at acpsolutions.com/oven-programming/.



Download and Install:

1. Open an internet browser and go to acpsolutions.com/oven-programming/.
2. Select the appropriate Remote Programming Interface download. (*Windows Download* or *Mac OS Download*) Your download will begin.
3. Open and install the downloaded ACP Remote Programming Interface:
 - **Windows:**
 - i. Open "DesktopRelease34"* compressed folder. Extract the file.
 - ii. Click to launch the extracted "DesktopRelease34.exe" file.
 - iii. Follow prompts to install the application to your C:\Program Files folder
**DesktopRelease34 current as of 3/23/2017. Version subject to change. Please use most recent release when available.*
 - **Mac OS:**
 - i. Locate the downloaded "ACP_MAC_Release_10_04_2016.dmg"* file.
 - ii. Drag and drop the "ACP_MAC_Release_10_04_2016.dmg" into your Applications folder
 - iii. Follow prompts to install the application
**ACP_MAC_Release_10_04_2016.dmg current as of 10/4/2016. Version subject to change. Please use most recent release when available.*



Getting Started:

1. Launch the application
 - **Windows:** Open "ACP Remote Programming Interface" from your Program Files, or the Start Menu shortcut: "ACP>ACP Remote Programming Interface"
 - **Mac OS:** Open the "ACP_Application.app" file
2. Start a New menu from scratch (a), or Open an existing menu (b):
 - a. **Create New Menu:**
 - i. Click "File", then "New."
 - ii. Select the appropriate model
 - b. **Open Existing Menu:**
 - i. Select "File," then "Open."
 - ii. Navigate to the location of your .xml file (or .acp)* and open it




* .xml file format for "AXP/MXP - touchscreen" models
.acp file format for all other models.

Change User Options:

1. To change the language, select from the top-right dropdown.
2. Click on the “User Options” tab to access a variety of customizable settings.


Note: The temperature set in the “User Options” section will be the default when creating a new menu item



Note: Available User Options vary with each model

Create/Edit a New Recipe:

1. Select the “Menu” tab.
2. Click on the Menu Item you would like create or edit.
3. Use the icons and menus to customize temperature, time, etc.*
*Select “No Preheat” under the “Temperature” menu to cook with microwave only. (For ACE, JET, AXP, or MXP only)



Save Menu Information

1. Save menu:
 - a. To save as a *new menu file*, select “File,” then “Save As.” or
 - b. To save changes to *existing menu file*, select “File,” then “Save.”
2. Navigate to the USB flash drive.
3. Specify a File Name* for the new menu. Click “Save.”

Note: For the MXP / AXP - touchscreen models there are no restrictions on file names.

*For all other models, files must be tagged with “ACP” and can only be transferred via USB.2.

For specific instructions on how to upload files to your oven, please see your model’s Owner’s Manual. Owner’s Manuals available online at acpsolutions.com/product-literature/

